

How to Install a Dynasys behind the fairings of a KW T680 with a usable step

Estimated time: 4- 5 hours first one, 2 hours after that.

11/18/2015



Finished installation with usable stels
Both fairings moved out 1" and it's virtually undetectable.



APU fits between tank and catwalk



1" spacers are inserted between bracket and fairing.
(Brace is left in original position at frame.)



Lower fairing bracket trimmed



Front fairing's rear mounting point is moved outward and anchored with only three bolts instead of four.
Bracket and fairing must both be trimmed.



Rear fairing mounting holes are moved out 1" in mud flap holder.



Some of catwalk must also be trimmed.



Heat shielding. Driver still plans to move exhaust away from APU with an "S" curve.